

ILLUS. KEY	PART NO.	DESCRIPTION	ALL	1	2	3	4	5
		<u>FRONT AND REAR HUBS, DRUMS AND WHEELS</u>		A	A	A	A	A
			MODELS	11	12	12	11	12
					W		E	E
	94375	RETAINER - Frt. Wheel Grease	2					
	94415	SEAL-Frt. Wheel Grease	2					
	94367	CONE - Frt. Wheel Bearing Inner	2					
	97706	HUB & DRUM ASSY. - Frt. R.H.	1					
	97705	HUB & DRUM ASSY. - Frt. L.H.	1					
	01956	CUP - Frt. Hub Bearing Inner	2					
	01957	CUP - Frt. Hub Bearing Outer	2					
	62540	STUD - Frt. Hub R.H.	5					
	62541	STUD - Frt. Hub L.H.	5					
	01961	STUD - Frt. & Rear Wheel Hub R.H. (.015 O.S.)	AR					
	01962	STUD - Frt. & Rear Wheel Hub L.H. (.015 O.S.)	AR					
	01966	DRUM - Frt. Wheel Bearing Outer	2					
	94365	CONE - Frt. Brake (Semi Finish Bore)	2					
	70285	WASHER - Strg. Knuckle Spindle	2					
	103385	COTTER PIN - Strg. Knuckle Spindle	2					
	98120	NUT - Strg. Knuckle Spindle	2					
	94363	CAP - Frt. Hub Grease	2					
	97704	HUB & DRUM ASSY. - Rear R. H.	1					
	97703	HUB & DRUM ASSY. - Rear L. H.	1					
	62540	STUD - Rear Hub R.H.	5					
	62541	STUD - Rear Hub L. H.	5					
	01961	STUD - Frt. & Rear Wheel Hub R.H. (.015 O.S.)	AR					
	01962	STUD - Frt. & Rear Wheel Hub L.H. (.015 O.S.)	AR					
	01966	DRUM - Rear Brake (Semi Finish Bore)	2					
	94382	GASKET - Rear Brake Oil Seal	2					
	95051	RETAINER ASSY. - Rear Brake Oil Seal	2					
	01995	SEAL - Rear Brake Oil Retainer	2					
	80294	KEY - Rear Hub to Axle Shaft	2					
	80029	WASHER - Rear Hub	2					
	03549	NUT - Rear Axle Shaft	2					
	103388	COTTER PIN - Rear Axle Shaft (1/8" x 1-3/4")	2					
	95407	WHEEL ASSY. - Frt. & Rear	5					
	94450	NUT - Wheel Frt. & Rear R.H.	10					
	94449	NUT - Wheel Frt. & Rear L.H.	10					
	98596	COVER - Wheel (Checker)	4					
	94677	CAP - Wheel Hub	4					
	81291	CLIP - Wheel Hub Cap Spring	15					