

WHEELS-HUBS-DRUMS GROUP V

PARTS LIST

No. Part
Req'd. Number

Description

HUBS AND DRUMS-FRONT

1	70304	HUB & DRUM ASSEMBLY—Right Front
1	70305	HUB & DRUM ASSEMBLY—Left Front
2	62400	HUB ASSEMBLY—Front (With Cups)
2	62408	CUP—Inner Bearing
2	62407	CUP—Outer Bearing
2	62402	DRUM—Brake
5	62540	STUD—Hub to Brake Drum—R. H. Std.
5	62541	STUD—Hub to Brake Drum—L. H. Std.
5	62404	STUD—Hub to Brake Drum—R. H. Oversize
5	62403	STUD—Hub to Brake Drum—L. H. Oversize
5	70296	NUT—Hub Stud Cap—R. H.
5	70297	NUT—Hub Stud Cap—L. H.
2	70299	CONE—Inner Bearing
2	70300	CONE—Outer Bearing
2	70302	SEAL ASSEMBLY—Oil
2	70303	CAP—Front Hub Grease

HUBS AND DRUMS-REAR

1	80026	HUB & DRUM ASSEMBLY—Right Rear
1	80027	HUB & DRUM ASSEMBLY—Left Rear
2	62401	HUB—Rear
2	62402	DRUM—Brake
5	62540	STUD—Hub to Brake Drum—R. H. Std.
5	62541	STUD—Hub to Brake Drum—L. H. Std.
5	62404	STUD—Hub to Brake Drum—R. H. Oversize
5	62403	STUD—Hub to Brake Drum—L. H. Oversize
5	70296	NUT—Hub Stud Cap—R. H.
5	70297	NUT—Hub Stud Cap—L. H.

WHEELS AND HUB CAPS

4	80028	DISC & RIM ASSEMBLY—Wheel
10	70296	NUT—Hub Stud Cap—R. H.
10	70297	NUT—Hub Stud Cap—L. H.
4	80040	CAP—Hub
12	62405	CLIP—Hub Cap
12	62406	RIVET—Hub Cap Clip