

# CHECKER MOTORS CORPORATION—PARTS CATALOG

## MODELS A9 A9L A10 A10L

GROUP 17

### OIL FILTER

<u>Illus.</u> <u>Key</u>	<u>Part</u> <u>No.</u>	<u>Description</u>	<u>Qty.</u> <u>Req'd</u>	<u>Model</u>
<u>OIL FILTER - THROW AWAY TYPE</u>				
(Extra Equipment)				
	95021	FILTER ASSEMBLY - Oil	1	ALL
	94540	BASE - Oil Filter Mounting	1	"
	138506	LOCKWASHER - Oil Filter Base Mounting (3/4 Ext.)	1	"
	219758	NUT - Oil Filter Base Mounting (3/4-16 Hex Jam)	1	"
	94541	BRACKET - Oil Filter Base Mounting	1	"
	120368	NUT - Oil Filter Base Bracket Mounting (5/16-24 Hex)	2	A9L-A10L
	120214	LOCKWASHER - Oil Filter Base Bracket Mounting (5/16)	2	" "
	120393	PLAINWASHER - Oil Filter Base Bracket Mounting (11/32 I.D. x 11/16 O.D.)	2	" "
	120741	BOLT - Oil Filter Base Bracket Mounting (5/16-24 x 3/4 Hex Hd.)	2	" "
	120382	LOCKWASHER - Oil Filter Base Bracket Mounting (3/8)	2	A9-A10
	122119	BOLT - Oil Filter Base Bracket Mounting (3/8-16 x 3/4 Hex Hd.)	2	" "
	92874	BRACKET - Oil Filter Base and Coil Mounting	1	A9L-A10L
	92875	BRACE - Oil Filter Base and Coil Mounting Bracket	1	" "
	120741	BOLT - Oil Filter Base Bracket and Coil Mounting (5/16-24 x 3/4 Hex Hd.)	2	" "
	120393	PLAINWASHER - Oil Filter Base Bracket and Coil Mounting (11/32 I.D. x 11/16 O.D.)	3	" "
	120214	LOCKWASHER - Oil Filter Base Bracket and Coil Mounting (5/16)	1	" "
	120368	NUT - Oil Filter Base Bracket and Coil Mounting (5/16-24 Hex)	2	" "
	95083	TUBE ASSEMBLY - Oil Filter Inlet	1	" "
	93929	TUBE ASSEMBLY - Oil Filter Inlet	1	A9-A10
	95084	TUBE ASSEMBLY - Oil Filter Outlet	1	A9L-A10L
	93930	TUBE ASSEMBLY - Oil Filter Outlet	1	A9-A10
	137405	CONNECTOR - Oil Filter Outlet Tube to Oil Filter	2	ALL
	137421	ELBOW - Oil Filter Tube to Engine Block	1	"
	94492	ELBOW - Oil Filter Inlet Tube to Engine Block	1	A9L-A10L
	137405	CONNECTOR - Oil Filter Inlet Tube to Engine	1	A9-A10
	94533	STREET TEE - Oil Filter Inlet Tube to Engine Block	1	" "
	94576	BRACE - Air Cleaner	1	A9L-A10L

# CHECKER MOTORS CORPORATION—PARTS CATALOG

## MODELS A9 A9L A10 A10L

GROUP 25

BODY FRAMING AND MOUNTING

Illus. Key.	Part No.	Description	Qty. Req'd.	Model
60-1	633126	BODY AND UNDER BODY ASSEMBLY - Stripped	1	ALL
<u>ROOF</u>				
	633057	ROOF ASSEMBLY - Panel (Use with Roof Lamp)	1	A9-A9L
	631402	PLATE AND BOLTS ASSEMBLY - Roof Lamp	1	" "
60-2	633047	ROOF ASSEMBLY - Panel	1	ALL
	634252	INSULATION - Roof Panel	1	"
	634069	BOW - Roof No. 1-2-3	3	"
	634070	BOW - Roof Rear	1	"
	633211	PANEL ASSEMBLY - Rear Window Finish Upper	1	"
60-3	633059	PANEL ASSEMBLY - Shelf	1	"
60-4	634181	PANEL - Deck Upper	1	"
60-5	633282	PANEL ASSEMBLY - Deck Lower and Cross Sill	1	"
60-6	633256	BRACKET ASSEMBLY - Deck Lid Lock Striker Mounting	1	"
60-7	634389	PANEL - Rear Cross Sill	1	"
	634363	REINFORCEMENT - Rear Cross Sill Center	1	"
	633034	PANEL AND NUTS ASSEMBLY - Deck Lower	1	"
<u>COWL AND WINDSHIELD</u>				
60-8	633362	POST AND COWL SIDE - Body Front R.H.	1	ALL
	630098	PLATE - Front Post Hinge Tapping	1	"
	630638	PLATE - Front Post Hinge Tapping	9	"
60-9	633361	POST AND COWL SIDE - Body Front L.H.	1	"
	633128	BRACKET ASSEMBLY - Foot Brake Parking	1	"
	630098	PLATE - Front Post Hinge Tapping	1	"
	630638	PLATE - Front Post Hinge Tapping	9	"
	633180	PANEL ASSEMBLY - Cowl Top	1	"
60-10	630268	HEADER - Windshield Opening Frame	1	"
60-11	633170	PANEL ASSEMBLY - Dash	1	"
	630399	BRACKET - Glove Compartment Support L.H.	1	"
60-12	633079	CONNECTOR ASSEMBLY - Air Duct to Dash	2	"
	633217	CONNECTOR ASSEMBLY - Dash to Blower	1	"
	633149	PLATE AND NUT ASSEMBLY - Treadle-Vac Mounting	1	"
	633176	REINFORCEMENT - Hood Hinge Mounting Dash	2	"
	633212	PANEL ASSEMBLY - Windshield Opening Inner Top	1	"
	631451	PANEL ASSEMBLY - Windshield Opening Inner L.H.	1	"
	631452	PANEL ASSEMBLY - Windshield Opening Inner R.H.	1	"
	633139	PANEL ASSEMBLY - Instrument	1	"